



Carpeting (1)

Shift lever sleeve (4)

Screw (2)

Cover (3)

remove

pull off

unscrew

lift at the rear, as well as at cutout of shift lever and remove toward the rear. During installation, pay attention to correct seat of holding cams (arrows).

For further installation proceed vice versa.